

							洗衣輔加功能	
Model 型號	Program 程式	Operation Time (min) 操作時間 (分鐘)	Default Water Level 設定水位	Operation Time by Water Level (min)	Max Load(kg) 最大洗衣容量(公斤)	Rinse Time	Reserve 預約	Soak 浸泡
ES-HK750X-W	Normal 標準	52	高 (高 / 中 / 低 / 少)	中 - 52 低 - 51 少 - 50	7.5	2	●	●
	Powerful 強力	69	高	-	7.5	2	●	●
	Gentle 輕柔	63	高 (高 / 中 / 低 / 少)	中 - 58 低 - 53 少 - 50	2.5	2	●	
	Quick Wash 快速	33	低 (中 / 低 / 少)	中 - 40 少 - 31	3.5	2	●	
	Wash 淨洗	20	高 (高 / 中 / 低 / 少)	中 - 20 低 - 17 少 - 14	7.5	-	●	
	Rinse 過水+脫水	45	高 (高 / 中 / 低 / 少)	中 - 43 低 - 40 少 - 39	7.5	2	●	
	Spin 脫水	13	-	-	7.5	-	●	
	Auto Tub Clean 筒槽洗淨	69	中 (高 / 中 / 低 / 少)	高 - 72 低 - 63 少 - 60	-	-	●	
ES-HK850X-W	Normal 標準	52	高 (高 / 中 / 低 / 少)	中 - 52 低 - 51 少 - 50	8.5	2	●	●
	Powerful 強力	69	高	-	8.5	2	●	●
	Gentle 輕柔	63	高 (高 / 中 / 低 / 少)	中 - 58 低 - 53 少 - 50	3	2	●	
	Quick Wash 快速	33	低 (中 / 低 / 少)	中 - 40 少 - 31	4	2	●	
	Wash 淨洗	20	高 (高 / 中 / 低 / 少)	中 - 20 低 - 17 少 - 14	8.5	-	●	
	Rinse 過水+脫水	45	高 (高 / 中 / 低 / 少)	中 - 43 低 - 40 少 - 39	8.5	2	●	
	Spin 脫水	13	-	-	8.5	-	●	
	Auto Tub Clean 筒槽洗淨	69	中 (高 / 中 / 低 / 少)	高 - 72 低 - 63 少 - 60	-	-	●	

The Soak program time varies with water level. It runs for 30 minutes at high and medium water levels, and 20 minutes at low and extra low water levels. Washing program will begin immediately after Soak completes. 浸泡的運行時間在不同水位時不一樣。高和中水位時浸泡程序為30分鐘。低和少水位時浸泡程序為20分鐘。在浸泡結束後，就會開始正常的洗衣程序。

NOTE: The Operation time may vary from above due to water temperature, wash load and other factor. The figures are for reference in condition of default setting, no load.
注意：由於水溫、洗滌容量和其他因素，操作時間可能會有所不同。以上是原廠設定、在沒有洗滌衣物的情況下作參考。