

SHARP

洗衣輔加功能

Model 型號	Program 程式	Operation Time (min) 操作時間 (分鐘)	Default Spin Speed 設定脫水轉速	Default Temperature 設定溫度	Max Load(kg) 最大洗衣容量(公斤)	Rinse Time 過水	Reserve 預約	Rinse 過水 (1-3)	Stain Master 智能污漬**	Prewash 預洗	Rapid wash 快速清洗	Vapour Wash 蒸氣護理	Anti-Allergy 防過敏	Saver 節能
ES-FS7ZH-W	Super Rapid 12' 超快洗	12	800 (800 - 0)	30°C (COLD / 30°C)	2	1	●					●		
	Fast 29' 29分鐘快洗	29	800 (1000 - 0)	30°C (COLD / 30°C)	4	1	●	●	●	●		●	●	
	Fast Cotton 44' 棉質快洗	44	1000 (1200 - 0)	40°C (COLD / 30 / 40 / 60°C)	7	1	●	●	●	●		●	●	
	Fast 59' 59分鐘快洗	59	1000 (1200 - 0)	60°C (COLD / 30 / 40 / 60°C)	7	1	●	●	●	●		●	●	
	Shirt/Curtain 襯衫/窗簾	77	800 (800 - 0)	40°C (COLD / 30 / 40°C)	3 襯衫 Shirt / 2窗簾 Curtain	3	●	●	●	●	●	●	●	●
	Rinse 過水	24	1000 (1200 - 0)	COLD	7	2	●	●				●	●	
	Spin/Drain 脫水/排水	15	1000 (1200 - 0)	COLD	7	-	●						●	
	ECO 40-60°C 節能洗	208	1200	40°C (40 / 60°C)	7	2	●							
	Cotton 棉質	110	1000 (1200 - 0)	60°C (COLD / 30 / 40 / 60 / 90°C)	7	1 (@60°C) 3 (@90°C) 4 (@40°C)	●	●	●	●	●	●	●	●
	Synthetics 合成纖維	135	1000 (1200 - 0)	40°C (COLD / 30 / 4°C)	3	3	●	●	●	●	●	●	●	●
	StainCare 加強去污	122	1000 (1200 - 0)	60°C (COLD / 30 / 40 / 60°C)	3	2	●	●	●					
	Colors/Bedding 護色	59	1000 (1200 - 0)	20°C (COLD / 20°C)	3	1	●	●	●	●			●	
	Wool/HandWash 羊毛/手洗	54	1000 (1200 - 0)	30°C (COLD / 30°C)	2	1	●	●		●			●	
	Mix 混合	87	800 (800 - 0)	40°C (COLD / 30 / 40°C)	4	3	●	●	●	●	●	●	●	●
Hygiene 抗菌護理	78	800 (800 - 0)	30°C (COLD / 30 / 40 / 60°C)	4	2	●		●	●			●	●	
ES-FS8ZH-W	Super Rapid 12' 超快洗	12	800 (800 - 0)	30°C (COLD / 30°C)	2	1	●					●		
	Fast 29' 30°C 29分鐘快洗	29	800 (1000 - 0)	30°C (COLD / 30°C)	4	1	●	●	●	●		●	●	
	Fast Cotton 44' 40°C 棉質快洗	44	1000 (1200 - 0)	40°C (COLD / 30 / 40 / 60°C)	8	1	●	●	●	●		●	●	
	Fast 59' 60°C 59分鐘快洗	59	1000 (1200 - 0)	60°C (COLD / 30 / 40 / 60°C)	8	1	●	●	●	●		●	●	
	Shirt/Curtain 襯衫/窗簾	77	800 (800 - 0)	40°C (COLD / 30 / 40°C)	4 襯衫 Shirt / 2窗簾 Curtain	3	●	●	●	●	●	●	●	●
	Rinse 過水	24	1000 (1200 - 0)	COLD	8	2	●	●				●	●	
	Spin/Drain 脫水/排水	15	1000 (1200 - 0)	COLD	8	-	●						●	
	ECO 40-60 節能洗	218	1200	40°C (40 / 60°C)	8	2	●							
	Cotton 棉質	110	1000 (1200 - 0)	60°C (COLD / 30 / 40 / 60 / 90°C)	8	1 (@60°C) 3 (@90°C) 4 (@40°C)	●	●	●	●	●	●	●	●
	Synthetics 合成纖維	135	1000 (1200 - 0)	40°C (COLD / 30 / 40°C)	4	3	●	●	●	●	●	●	●	●
	StainCare 加強去污	122	1000 (1200 - 0)	60°C (COLD / 30 / 40 / 60°C)	4	2	●	●	●					
	Colors/Bedding 護色	59	1000 (1200 - 0)	20°C (COLD / 20°C)	4	1	●	●	●	●			●	
	Wool/HandWash 羊毛/手洗	54	1000 (1200 - 0)	30°C (COLD / 30°C)	2	1	●	●		●			●	
	Down 羽絨護理	87	800 (800 - 0)	40°C (COLD / 30 / 40°C)	3	3	●	●	●	●	●	●	●	●
Hygiene 抗菌護理	78	800 (800 - 0)	30°C (COLD / 30 / 40 / 60°C)	4	2	●		●	●			●	●	

*Stain Selection: Sweat, Coffee, Oil, Mix 污漬類型: 汗, 咖啡, 油, 混合
90°C滾筒清潔: 88分鐘 600轉

NOTE: The Operation time may vary from above due to water temperature, wash load and other factor. The figures are for reference in condition of default setting, no load.
注意: 由於水溫、洗滌容量和其他因素, 操作時間可能會有所不同。以上是原廠設定、在沒有洗滌衣物的情況下作參考。